

C. R. LAURENCE CO., INC.


ASSEMBLY INSTRUCTIONS FOR: COMPACT-X70 SHOWER KIT



SA/BN/CH

SHOWER 180°		SHOWER 180°		GLASS WIDTH CALCULATION	
Z					
Y				1	2
X				3a	
V				3b	
CRL3978SA/BN/CH/DU/BR				4	5
S				6	
CRL					
r					

$A = H - 43\text{mm}$
 $A = H - 1 \frac{11}{16}"$
 $F = H - 70\text{mm}$
 $F = H - 2 \frac{3}{4}"$



038

AVDB3347_01/17



C. R. LAURENCE CO., INC.

ASSEMBLY INSTRUCTIONS FOR: COMPACT-X70 SHOWER KIT

CLAMPS ASSEMBLY / ASSEMBLAGE PINCES / MONTAJE PINZAS

7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25

1mm - 1/16" ↔ 8mm - 5/16"
3mm - 1/8" ↔ 10mm - 3/8"

ANTI-SHOCK SCREW
ANTI-DERAILMENT SCREW
CLAMP TIGHTEN SCREWS
HEIGHT ADJUSTMENT SCREW
(x4) GLASS THICKNESS SETTINGS SCREW

13 N/m

IMPORTANT!
*T-SHAPE ACTIVATOR HAVE TO BE LOADED AS SHOWN TO WORK CORRECTLY.

315mm
12 7/16"

43mm
1 11/16"

43mm
1 11/16"

635mm
MIN 25"

10mm
3/8"

DON'T REMOVE FLOOR SPACERS

V₁ 8,5
V₂ 12,5

X ≤ 8mm
X > 8mm

±3mm
± 1/8"

2mm
1/16"

ANTI-DERAILMENT / ANTI-DÉRAILLEMENT / ANTIDESCARRILAMIENTO

Ok!

AVDB3347_01/17



C. R. LAURENCE CO., INC.

ASSEMBLY INSTRUCTIONS FOR: COMPACT-X70 SHOWER KIT

INSTALLATION WITH CRL 90° KIT <u>LEFT</u> OR <u>RIGHT</u> SA/BN/CH (Not included with Kit)						SHOWER 90°	SHOWER 90°	LATERAL PANEL	
1	1	1	1	1	1				
INSTALLATION WITH CRL 90°KIT <u>RIGHT</u> + <u>LEFT</u> SA/BN/CH (Not included with Kit)						SHOWER 90°	SHOWER 90°	LATERAL PANEL	
2	2	2	2	1	1			<div style="border: 1px solid black; padding: 2px; display: inline-block;"> G= H G= H </div>	

AVDB3347_01/17