

90° Glass-to-Glass Hinge -"T" Configuration CAT. No. GENT90

| *Maximum | 3/8" (10mm) Glass | | 1/2" (12mm) Glass | |
|-----------------|-------------------|------------|-------------------|------------|
| Door Capacities | Weight Width | | Weight Width | |
| Using 2 Hinges | | 28"(711mm) | 80 lbs.(36 kg) | 28"(711mm) |
| Using 3 Hinges | | 32"(813mm) | 120 lbs.(54 kg) | 32"(813mm) |

^{*}NOTE: Do not exceed either maximum weight or width when choosing proper quantity of hinges.

Important Information:

- 1) This hinge contains a dual degree pivot pin. The pivot pin is set for normal door closing position. You have the option of altering the closing position of the door 5 degrees inward by utilizing the opposite side of the pivot pin, which has been pre-machined (see Section 3 of Cat. No. SDT21 Frameless Shower Door Guide for this procedure). Special order custom pivot pins are available (Cat. No. GENP1N) that can be machined at any angle up to 45 degrees.
- 2) The doors and fixed panel require different fabrication.

Specifications:

Glass Sizes: 3/8" (10mm) to 1/2" (12mm) thick tempered safety glass

Construction: Solid brass

Closing Type: Self-centering when within 15° of closed position **Cutout Required:** For Door **Holes Required:** For Panel

Includes: Gaskets, screws and template

Use of Gaskets:

For 3/8"(10mm) Glass: Use one thick gasket on each side For 1/2"(12mm) Glass: Use one thin gasket on each side

Recommendations:


For public safety, we recommend the use of only tempered safety glass. Do not use power tools when installing these hinges.


Maintenance Guidelines:


- Our hinges are greased at the factory for guiet and trouble-free operation. If there is any squeaking that occurs after installation, put a drop of "3 in 1 Oil" (also known as "household oil") on the white nylon washer that the hinge body pivots on. This washer is the component that acts as a buffer, so the body of the hinge doesn't pivot directly on the brass center block. This solution doesn't require the disassembly of the hinge. Note: Do not use spray lubricant on these hinges. If the hinge has been disassembled, upon re-assembly, use white lithium grease to lubricate the interior mechanism.
- Never use an abrasive cleaner on the hardware. Many of the components are coated with a clear lacquer that will be irreparably damaged if subjected to harsh, abrasive chemicals. Advise your customer that drying the hardware with a clean, soft towel on a daily basis is the best way to maintain the hardware. If mineral deposits build-up, mix a couple of drops of a mild liquid soap (such as Ivory or a similar product) into a cup of warm water. Using a soft, non-abrasive cloth, clean the hardware. Rinse thoroughly with clean, warm water and dry.

4B-33









GENEVA

90° Glass-to-Glass Hinge -"T" Configuration

CAT. No. GENT90